
ZA 22 THIXO BODY: Technical Data Sheet

1. Description and Main Features

ZA 22 THIXO BODY is a bicomponent (base and catalyst) addition RTV 2 silicone rubber that vulcanizes at room temperature.

2. Main Fields of Application

Body casting

Special effects

3. Instructions for use

Take the two bi-component products supplied by Zhermack (base and catalyst). Weigh an equal amount of catalyst and base (ex. 100 grams of catalyst and 100 grams of base; within a 5% error range the end result is not altered). When extruding the product from the container it is necessary to use two different spoons for each component to prevent contamination of the product. Once the product is weighed and it is assured that the base and catalyst are equal, the two components are inserted in a recipient and mixed thoroughly. It is important to check while mixing that no residue remains on the base and sides of the recipient. Mix energetically until the colour of the product is homogeneous. Once the product is mixed it is applied to the mould or body. The working time is approximately WT (see table below) from the beginning of the mixing at 23°C. If the quantity used is less than what is needed to complete the duplication, complete the hardening of the silicone and then proceed with the addition of the remaining silicone needed. The material attaches to the silicone without altering the final result.

The setting time (time the silicone needs to vulcanize) is about ST at 23°C (see table below). After the ST is complete, from the start of the mixing, we can separate the model from the mould. If necessary use compress air to facilitate this separation. It is important not to force this separation with sharp objects that can deform the final stamp.

Note: The working time and thus the setting time are reduced if the temperature exceeds 23°C (ex. If the temperature is 40°C, the working time is halved and the setting time is approximately halved). If the temperature is less than 23°C both the working time and setting time increase considerably. (ex. If the temperature is 4°C, the working time doubles and the Setting time increases three times the minutes indicated at 23°C). .

4. Important Recommendations

The exact proportions 1 : 1 must be respected to obtain the correct times and not to alter the final characteristics of the product. The surfaces with which the material enters in contact must be perfectly clean, free of grease and dry.

NB: before use, we recommend the two components be homogenized so as to avoid sedimentation.

5. Chemical and Physical Properties

Vulcanized product

TYPICAL PROPERTIES	
Vulcanized color	Skin tone
Mixing ratio	1: 1
Viscosity of pre-catalyzation mixture	> 50'000cP
Working time at 23 °C (73 °F)	6^{min} 00^{sec}
Setting time at 23 °C (73 °F)	15^{min} 00^{sec} ÷ 20^{min} 00^{sec}
Shore A hardness after 24 hours	22 ± 2 shA
Tensile Strenght	3.0 ± 0.3 N/mm²
Elongation at break	400 ± 20 %
Tear strength	>14 ± 1 N/mm
Reproduction of details	2 micron
Dimensional variation after 24 hours	-0.05 %

6. Available Packages

<i>Packages</i>
DT23334 1 kg + 1 kg
DT23335 3 kg + 3 kg
DT23336 25 kg + 25 kg

7. Safety Data Sheets

The safety data sheets are available at Zhermack SpA.

The preparation is not to be considered hazardous in accordance with directive 88/379/CEE and subsequent amendments.

8. Shelf Life

The ZA 22 THIXO BODY is guaranteed for a period of 12 months if stored correctly at a temperature of between 5° - 27°C (41° - 80°F).

Close the bottles after use, do not invert the caps or lids between the base and catalyst.

IMPORTANT OBSERVATIONS

The advice given verbally, in writing or through demonstrations on the use of the products are based on our knowledge. The use and application of the product by the user lie beyond the control of the company and are therefore the user's own responsibility.